

# InteraTARP Patent Pending

[www.interatarp.com](http://www.interatarp.com)



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

## INSTALLATION INSTRUCTIONS

### Step One

Place the InteraTARP in the cargo area behind the front seats and unfold toward the rear of the vehicle (figure 1).

### Step Two

Unfold the box end and place the box end cord over the front seat headrests (figure 2). Use the sliding cord lock to take up any slack in the cord.

### Step Three

Unfold one side of the InteraTARP and hook the front side cord over the garment hook (figure 3). If there is no garment hook, use the provided accessory hook and suspend from the grab handle.

### Step Four

Go to the rear of the vehicle and suspend the side panel cord to the rear garment hook or attach the suction cup to the rear side window approximately half way up the glass (figure 4). On X-Large size, suspend both middle and rear section of cord from rear garment hook (figure 5.) Use the sliding cord lock to take up any slack in the cord (figure 6).

Repeat steps #3 and #4 on the opposite side of the vehicle.

## REMOVAL INSTRUCTIONS

Remove the suspension cord from side hooks. Release suction cups by pulling on small tabs. Remove cord from headrests.

Fold box end first so that the side panels fold on top (figure 7).

Fold side panels toward middle and fold in half lengthwise.

Roll up from rear of vehicle and secure with cord loop and sliding lock (figure 8).

## TRIPLE GUARANTEE

**Fit.** If for any reason the InteraTARP does not fit your vehicle, return it within 30 days for a full refund of purchase price and return shipping charges (Maximum USPS Parcel Post).

**Satisfaction.** If you are not satisfied for any reason, return the InteraTARP within 30 days for full refund of purchase price and return shipping charges (Maximum USPS Parcel Post).

**Performance.** If any seam, grommet or cord fails within 5 years of date of purchase we will, at our option, repair or replace your InteraTARP.



Figure 6



Figure 7



Figure 8



Properly Installed InteraTARP

**Customer Service: call 1-888-214-TARP or email [customersupport@interatarp.com](mailto:customersupport@interatarp.com)**